



Prime lens

Half frame 35mm F0.95

User manual

## 01 / Identifying the Parts



### 02 / Product Parameters

Lens type Product mode Picture size
Prime lens 35mm F0.95 APS-C

Focus Length Aperture range Lens Barrel Materia

35mm F0.95-F16 Metal

Aperture ring Lens type Aperture blade


Graded aperture 9 groups 12 pieces 12 pcs

Shooting distance Viewing Angle Filter size 0.35m to infinity 44° 52mm


Weigh Mount

 $\approx$ 393g E/Z/FX/M43/EOS-M/R/L

# 03 / Optical structure diagram



# 04 / MTFGraph



## 05 / Lens change procedure

- First of all, you need to remove the lens from the camera, press the body lens removal button, turn the lens counterclockwise to remove.
- Secondly, set the camera to no lens release mode, otherwise the camera will not be able to take pictures.
- 3.Finally, align the lens bayonet marker with the fuselage bayonet marker and rotate it clockwise. The sound "click" means the lens is in place and the sound means the lens is in place.





#### 06 / Attentions



# The following may cause injury to the user or damage to the product.

- Do not point the lens directly at the sun when taking pictures, as this may cause eye injury.
- Keep the lens away from direct sunlight and use the lens cap, otherwise it may cause a fire alarm.
- 3.Do not place in a dark and damp position, or allow the product to be impacted to avoid lens damage.
- If the lens is dirty or dusty, wipe it with a suitable lens cloth.
- 5.Do not disassemble it by yourself. If there is a fault, contact the dealer for handling.

#### Tips:

- 1.Do not wrap the lens too tightly when storing , the lens should be in a ventilated state , so that the lens is fully ventilated and dry, which can effectively prevent the lens from moldy .
- 2.Often wipe the lens with a cotton swab to  $\;$  prevent grit and dust from  $\;$  rubbing the  $\;$  lens .